ESP32 and IoT

Introduction



Course Introduction



What is ESP32?

- Microcontroller?
- SoC System on Chip
- Far complex than general purpose microcontroller
- Meant for IoT Applications
- Developed by expressif systems



Applications?

- Home Automation
- Smart Agriculture
- Smart Building / lightening
- Healthcare
- Toys / wearable electronics

ESP32 Chip and Modules

- Various modules makes it easier to use esp32 chip

Which Modules to use?

- Lots of different modules available
- Different manufacturers, different pinouts
- Issue in learning is common ground
- We’re going to use Adafruit Huzzah32 Feather Module
- Universal, available across globe

ESP32 Huzzah

Pinout of Adafruit Huzzah32 → Power Pins



Pinout of Adafruit Huzzah32 → GPIO



Bottom Row



- **RST , 3v, GND**
- **A0** - this is an analog input A0 and also an analog output DAC2. It can also be used as a GPIO #26. It uses ADC #2
- **A1** - this is an analog input A1 and also an analog output DAC1. It can also be used as a GPIO #25. It uses ADC #2
- **A2** - this is an analog input A2 and also GPI #34**. Note it is *not* an output-capable pin! It uses ADC #1**
- **A3** - this is an analog input A3 and also GPI #39. **Note it is *not* an output-capable pin! It uses ADC #1**
- **A4** - this is an analog input A4 and also GPI #36. **Note it is *not* an output-capable pin! It uses ADC #1**
- **A5** - this is an analog input A5 and also GPIO #4. It uses ADC #2
- **SCK, MO, MI** – SPI Pins
- **RX, Tx** – Uart Pins
- **21** - General purpose IO pin #21

Top Row



13 - This is GPIO #13 and also an analog input A12 on ADC #2. It's also connected to the red LED next to the USB port

12 - This is GPIO #12 and also an analog input A11 on ADC #2. This pin has a pull-down resistor built into it, we **recommend using it as an output only,** or making sure that the pull-down is not affected during boot.

27 - This is GPIO #27 and also an analog input A10 on ADC #2

33 - This is GPIO #33 and also an analog input A9 on ADC #1. It can also be used to connect a 32 KHz crystal.

15 - This is GPIO #15 and also an analog input A8 on ADC #2

32 - This is GPIO #32 and also an analog input A7 on ADC #1. It can also be used to connect a 32 KHz crystal.

14 - This is GPIO #14 and also an analog input A6 on ADC #2

SCL, SDA – I2C Pins

Important Note

- Note you can only read analog inputs on **ADC #2** once WiFi has started as it is shared with the WiFi module.

ADAFRUIT HUZZAH32 PIN DIAGRAM

A13 not exposed. It's used for measuring the voltage on the battery. The voltage is divided by 2 so multiply the analogRead by 2.

GPIO#12 Used for booting up. Adafruit suggests not using it or only using for output.

ADC#2 does <u>not</u> work when WiFi is activated. The ESP32 internally uses ADC#2 for WiFi

PWM is possible on every GPIO pin

		I2C SDA	GPIO #23
		I2C SCL	GPIO #22
TOUCH6	A6 ADC#2		GPIO #14
TOUCH9	A7 ADC#1		GPIO #32
TOUCH3	A8 ADC#2		GPIO #15
TOUCH8	A9 ADC#1		GPIO #33
TOUCH7	A10 ADC#2		GPIO #27
TOUCH5	A11 ADC#2		GPIO #12
TOUCH4	A12 ADC#2		GPIO #13
		Positive voltage from USB jack, if connected. ~5V	
		Drive LOW to disable 3.3V regulator	
		Positive voltage from LiPoly battery, if connected. ~3.7V	

		GPIO #21	
		GPIO #17	
		GPIO #16	
		GPIO #19	SPI MISO
		GPIO #18	SPI MOSI
		GPIO #5	SPI SCK
TOUCH0	A5 ADC#2	GPIO #4	
	A4 ADC#1	GPI #36	
	A3 ADC#1	GPI #39	
	A2 ADC#1	GPI #34	
DAC1	A1 ADC#2	GPIO #25	
DAC2	A0 ADC#2	GPIO #26	
		GND. Common ground for power and logic	
		No connect pin (not used)	
		3.3V output from on-board regulator. Can supply up to 500mA.	
		Drive LOW to reset (or press Reset button)	

By @jonfroehlich

Peripherals Needed for This Course

- Micro USB Cable x 1
- Adafruit Huzzah32 Feather Board x 1
- Bread board x 1
- Few LEDs
- Tactile button / switches
- Relay Module
- DHT22 Temperature and Humidity Sensor
- HC-SR04 Ultrasonic Distance Sensor
- A digital Multi meter
- Connecting Wires

How to add Adafruit Huzzah32 to Arduino

- https://learn.adafruit.com/adafruit-huzzah32-esp32-feather/using-with-arduino-ide
- Install Arduino from Arduino.cc
- https://docs.espressif.com/projects/arduino-esp32/en/latest/installing.html

Add below link to preferences of Arduino

- https://raw.githubusercontent.com/espressif/arduino-esp32/gh-pages/package_esp32_index.json

Search for Board

- Open Boards Manager from Tools > Board menu and install esp32 platform (and do not forget to select your ESP32 board from Tools > Board menu after installation).

Serial Communication

Between esp32 and Computer

Why?

- Easiest output device
- Can print text of any length
- Gives a quick way to print data
- Simple to use

Basics of Serial Communication

Serial Communication Library in Arduino

- begin ()
- write ()
- print ()
- println ()
- available()
- read()

Blink Code

- pinMode
- digitalWrite


POWER AND FILTERING
VBUS
VBAT
DMG3415U
Q3
D4
MBR120
R12
100K
U2
IN
OUT
EN
GND
P4
AP2112-3.3
R7
100K
C6
10µF
C8
10µF
C7
1uF
3.3V
GND
EN
JSTPH
X1
C1
10uF
RESET
R13683
10K
SW2
KMR2
C4
1uF
ESP3212 MODULE + AUTORESET
NC: IO0,IO2
VBAT SENSE: IO35
LED: IO13
EN
IO36/SEN_VP/A1_0
IO39/SEN_VN/A1_3
SD2
SD3
CMD
CLK
SD0
SD1
RXD0
TXD0
IO0/A2_1
IO2/A2_2
IO4/A2_0
IO5
IO12/A2_5
IO13/A2_4
IO14/A2_6
IO15/A2_3
IO16
IO17
IO18
IO19
IO21
IO22
IO23
IO25/DAC1/A2_8
IO26/DAC2/A2_9
IO27/A2_7
IO32/A1_4/X32P
IO33/A1_5/X32N
I34/A1_6
I35/A1_7
GPIO0
GPIO2
A5_IO4
SCK
IO12_A11
IO13_A12
IO14_A6
IO15_A8
IO16
IO17
MOSI
MISO
IO21
SCL
SDA
A1_DAC1
A0_DAC2
IO27_A10
IO32_A7
IO33_A9
A2_I34
A13_I35
R1
100K
R3
100K
A13_I35
RTS
DTR
10K
R136$2
R136$4
Q2
mmbt2222
Q1
mmbt2222
RESET
LIPO CHARGING
10K = 100mA
5.0K = 200mA
2.0K = 500mA
1.0K = 1000mA
U3
MCP73831/2
LIPO Charger
VDD
VBAT
PROG
STAT
VSS
VDD: 3.75-6V
Temp: -40-85°C
MCP73831T-2ACI/OT
CHG
ORANGE
R2
1K
4.7K
R4
C3
10µF
LED
D3
RED
R10
4K
IO13_A13
USB TO SERIAL CONVERTER
IC1G$1
CP2104
USB/UART BRIDGE
VIO
VDD
REGIN
#RST
#SUSPEND
SUSPEND
GPIO0/TXLED
GPIO1/RXLED
GPIO2
GPIO3
VBUS
D+
D-
UD
GND
VPP
NC
RI
DCD
DTR
DSR
TXD
RXD
RTS
CTS
VIO: 1.8-VDD
Op. Temp: -40°85°C
CP2104
C2
10uF
X4
20329
DTR
RXD0
TXD0
RTS
IC1G$2
THERMAL
PAD
JP3
JP1
ISSUE
ADAFRUIT INDUSTRIES
© >YEAR
DRAWN
KTOWN
TITLE
REV
B
CHECKED
>CHECKED
DATE
5/10/2017 4:48:57 PM
DRG Nº
>DRGNO
DATE
>DATE
FILE: ESP32 rev C
PAGE: 1/1

Interfacing of 4 x LEDs with ESP32 Huzzah Boad





Accepting digital Input on ESP32

Pull Up Resistor

Pull Down Resistor


Adafruit Feather Huzzah32
1 RESET
2 3V
3 NC
4 GND
5 DAC2/A0
6 DAC1/A1
7 GPIO34/A4
8 GPIO39/A3
9 GPIO36/A4
10 GPIO4/A5
11 GPIO5/SCK
12 GPIO18/MOSI
13 GPIO19/MISO
14 GPIO16/RX
15 GPIO17/TX
16 GPIO21
28 VBAT
27 EN
26 USB
25 GPIO13/A12
24 GPIO12/A11
23 GPIO27/A10
22 GPIO33/A9
21 GPIO15/A8
20 GPIO32/A7
19 GPIO14/A6
18 GPIO22/SCL
17 GPIO23/SDA
KEY1
1
2
KEY2
1
2
GND

Tasks Based on Switch

- Up Down Counter using switch
- LED Control using switch
- 2 LEDs and 2 switches. When one switch is pressed, both ON and when other switch is pressed both OFF
- 2 LEDs and 2 switches. When one switch is pressed, LED2 OFF and LED1 ON when another switch is pressed LED1 OFF and LED2 ON



Switching Circuits

With esp32

Transistorized Switching



→ DC Load switching

→ AC load switching

motor | Buzzer | LEDs





Relay Interfacing

With esp32

Output Relay





Relay Switching Circuit



Touch Input on ESP32

Adafruit Huzzah32 Board

How to accept capacitive touch on esp32 Feather Board (touchread)

- 14
- 32
- 15
- 33
- 27
- 12
- 13
- 4



Sensors Interfacing

To esp32



Types of Sensors

- Analog Sensors
  - Give a specified 0-X volt dc output
  - Need adc to use
- Digital Sensors
  - Either give a straight 1/0 output
  - Gives digital data over some protocol
  - Onewire / spi / i2c

Why no Analog?

- ESp32 analog input pins are non-linear
- Lot of confusion in documentation about the usability
- No fixed reference voltage
- If you want to use analog sensors, use an external ADC Chip



DHT22

Interfacing with ESP32



DHT22

- -40 to 80 °C
- 0 to 100% Humidity
- 3 – 6 V DC Operating voltage
- Resolution : Humidity: 0.1%, Temperature: 0.1°C



DHT22 Pinout

- Pin 1 → 3.3v
- Pin 2 → GPIO with 10k Pullup
- Pin 3 → NC
- Pin 4 → GND


1
TEMP-HUM-SENSOR-DHT22
VDD
DAT
N.C.
GND
1
2
3
4
MS1
Adafruit Feather Huzzah32
1 RESET
2 3V
3 NC
4 GND
5 DAC2/A0
6 DAC1/A1
7 GPIO34/A4
8 GPIO39/A3
9 GPIO36/A4
10 GPIO4/A5
11 GPIO5/SCK
12 GPIO18/MOSI
13 GPIO19/MISO
14 GPIO16/RX
15 GPIO17/TX
16 GPIO21
28 VBAT
27 EN
26 USB
25 GPIO13/A12
24 GPIO12/A11
23 GPIO27/A10
22 GPIO33/A9
21 GPIO15/A8
20 GPIO32/A7
19 GPIO14/A6
18 GPIO22/SCL
17 GPIO23/SDA
R1
10k

Library needed

- Open your Arduino IDE and go to Sketch > Include Library > Manage Libraries. The Library Manager should open.
- DHT Sensor Library by Adafruit
- Adafruit Unified Sensor Library

Lets test ☺

Wifi Device Control

Using esp32

Concept


Home Wifi Router
ESP32
(as server)
Relay + Switching Circuit
Phone / Laptop
Browser

Wifi Device Control

- Esp32 acts as a mini http server
- Serves a small web page
- You can take actions in this page
- Relay / LED Control

Schematic for this Experiment



Required Libraries

- AsyncTCP – – Download here 

- ESPAsyncWebserver -- Download here 

- Extract the library and copy the folder into
- Program files → Arduino (x86) → Libraries

Test the Code

- Insert your Wifi Credentials
- Upload the Code
- Open Serial Terminal with baud rate of 9600
- Reset The ESP32
- Check IP Address assigned to esp32
- Open that IP Address on Phone / computer browser



Weather Monitoring

Using ESP32 and DHT22 in LAN

Concept


Home Wifi Router
ESP32
(as server)
DHT22
Phone / Laptop
Browser

Required Libraries

- AsyncTCP – – Download here 

- ESPAsyncWebserver -- Download here 

- DHT Sensor Library by Adafruit
- Adafruit Unified Sensor Library
- Program files → Arduino (x86) → Libraries


1
TEMP-HUM-SENSOR-DHT22
VDD
DAT
N.C.
GND
1
2
3
4
MS1
Adafruit Feather Huzzah32
1 RESET
2 3V
3 NC
4 GND
5 DAC2/A0
6 DAC1/A1
7 GPIO34/A4
8 GPIO39/A3
9 GPIO36/A4
10 GPIO4/A5
11 GPIO5/SCK
12 GPIO18/MOSI
13 GPIO19/MISO
14 GPIO16/RX
15 GPIO17/TX
16 GPIO21
28 VBAT
27 EN
26 USB
25 GPIO13/A12
24 GPIO12/A11
23 GPIO27/A10
22 GPIO33/A9
21 GPIO15/A8
20 GPIO32/A7
19 GPIO14/A6
18 GPIO22/SCL
17 GPIO23/SDA
R1
10k



IoT

Introduction

Internet of Things

What is IoT?

Your things + sensors

Data analysis + insights

Actions + decision making



Data



Data

Things

(Sensors, actuators, MCU/MPU, network, energy, firmware)

Connectivity

(PAN, LPWAN, Cellular)

People & Processes

(IoT Cloud, Machine Learning, AI)


Thing
Inputs
Sensors
Output
Devices
Controller
Network
Interface
Internet
Software
wifi
ESP32
wifi
Raspi
uC


Wifi
LAN
BLE
LoRa
cloud
infon
S1
zigbee
LAN
zigbee
Computer
S2
Sn
Photon
Sim
Card

Applications

- Consumer
- Industrial
- Commercial
- infrastructure





IoT Architecture Requirements

- Handle proper hardware and software heterogeneity.
- Reliability
- Scale
- Data latency.
- Be secure by design
- Lower barriers to entry: evaluate -> prototype -> deploy
- Manufacturable

Technologies Involved

Programming in

C / C++

Python

Web development (all web tech)

Machine Learning

Cloud software

Data analysis

App development

Protocols

Data sending from device to Cloud

HTTP

MQTT



Hardware

Microcontroller

Sensors

Devices



Choice of Cloud Service

1. Custom Design with Major Cloud Providers

2. Using existing service Providers optimized for IoT

Ready Service Providers

- Thingworx
- Everythng
- Sensorcloud
- Device Cloud
- ThingSpeak
- Numerex

Internet of Things

Industrial

MANUFACTURING
- OEE Monitoring (Runtime, Availability, Quality monitoring)
- Energy efficiency
- Preventive & predictive maintenance
- Supply chain management

MINING / OIL & GAS
- Equipment monitoring
- Asset tracking
- Production monitoring

AGRICULTURE
- Environmental monitoring
- Irrigation management
- Product yield monitoring
- Water management

UTILITIES
- Smart meters
- Electrical Grid Management
- Power line monitoring
- Water & Waste management

SMART CITIES
- Smart parking
- Environmental monitoring
- Roads, Traffic & Transport
- Social & Security

Commercial

HOSPITALITY
- Energy Efficiency & HVAC
- Location-based information
- Occupancy monitoring
- Customer service scoring

HEALTHCARE
- Cold-chain monitoring
- Patient monitoring
- Virtual care
- Wellness & Prevention

RETAIL
- In-store promotions
- Shopper analytics
- Smart ordering & payment
- Vending machines

Protocols used in IoT

- **AMQP** stands for Advanced Message Queueing Protocol and is an open standard application layer protocol.
- **MQTT** stands for Message Queuing Telemetry Transport machine-to-machine connectivity protocol designed as a lightweight publish/subscribe messaging transport, which makes it very suitable for use with IoT
- **HTTP** stands for Hypertext Transfer Protocol is an application protocol for distributed, collaborative, and hypermedia information systems

Project 1 : Temperature and Humidity Logging in Cloud



Thingspeak

- Free for up to 8 fields
- 15 second refresh time
- Lots of online apps can be developed for analytics

Thingspeak and HTTP

- You can send requests to thingspeak server via http requests
- Easiest to create IoT Application
- Thingspeak account + write API Key + esp32
- Thingspeak adafruit library
- DHT22 connected to esp32 board

Project 1 : Temperature and Humidity Logging in Cloud



Required Libraries

- DHT Sensor Library by Adafruit

Thingspeak analytics

- Goto profile, copy alert API key
- Matlab Analysis Code
- Goto apps → Matlab analysis → New → Paste the code → Save
- Goto apps → React
- Used as A rection for something

Matlab Code (Alert api key needs replacement)

```
alert_body = 'This is the text that will be emailed';
alert_subject = 'This will be the subject of the email';
alert_api_key = 'TAK5Q7V3N5EEH07FXD658';
alert_url= "https://api.thingspeak.com/alerts/send";
jsonmessage = sprintf(['{"subject": "%s", "body": "%s"}'], alert_subject,alert_body);
options = weboptions("HeaderFields", {'Thingspeak-Alerts-API-Key', alert_api_key; 'Content-Type','application/json
result = webwrite(alert_url, jsonmessage, options);
```

What is MQTT

Adafruit IO


adafruit
SHOP
BLOG
LEARN
FORUMS
Weather Station
FULLSCREEN
DONE
PRIVATE
DELETE
MANAGE GROUPS
MANAGE FEEDS
NEW BLOCK
VIEW AIO KEY
Local Weather Station
Humidity
51
0
Temperature
65
64
62
60
58
56
54
52
50
49
Temperature
10:39:06
10:39:10
10:39:15
10:39:20
10:39:25
10:39:30
Time
Station Reset
RESET
Station Power
OFF
Temperature
59
Battery Remaining
4
Volts
Temperature
59
F

MQTT Fundamentals

- Broker address
- Username and pwd
- Mqtt topic name

Adafruit IO

- Io.adafruit.com
- Account creation
- Creation of and understanding Feeds
- Creation of Dashboard
- Adafruit MQTT Library
- Free Account supports 5 different fields (or topics)
- Trial Code

Adafruit IO MQTT Example (feeds)

- Temperature
- Humidity
- Relay

Circuit Wiring : DHT22 and Relay



Alexa Controlled Home Lamp

Things you'll need

- Alexa echo or alexa app
- IFTTT account
- Adafruit IO Account and the Same last Arduino Code

Flow

- Alexa sends command to IFTTT Server
- IFTTT Will send command to adafruit broker
- Adafruit Broker will update the value of relay feed
- Esp32 is subscribed to relay feed to it receives it
- ESP32 turns on/off relay